

Application: 1997–2004 C5 Corvette

INSTRUCTION SHEET

Part Number

630-587

Part Includes

- 2 Stainless Side Marker Trim
- 1 Adhesive Promoter Pack
- 1 Adhesive Promoter Tube
- .. 2 17" of 1/4" Chrome Trim

Side Marker Trim







STEP 1.

Thoroughly clean the factory plastic side marker with alcohol to remove any and all wax and dirt. Swipe the entire factory lens with the adhesive promoter pack provided (save enough promoter for the opposite side). Allow a few seconds to dry.

STEP 2.

Before permanently attaching the stainless bezel, set it in place to get acquainted with the position. A properly placed bezel will set perfectly centered evenly all around the perimeter of the factory lens. Peel the release liner from the back of the new bezel and carefully set in place. Press firmly along the entire stainless bezel to make sure it has a complete bond.

STEP 3.

To install the chrome trim, apply a single bead of adhesive promoter tube (provided) along the outer edge of the factory lens. Make sure that the end of the chrome trim is square. Pull the read release liner from the back of the trim and set it at the very bottom center of the factory red lens and work the trim around the lens at the same time. Try to set the trim tightly against the stainless cover. After reaching the start point, mark that point by pressing a fingernail into the trim. Doing this will give an indication where to cut the excess. Apply a tiny drop of instant adhesive to the edge of the trim and then set the 2 ends together, pressing firmly to set the entire length of the trim.

DO NOT GET WET FOR 24 HOURS!





Mamotorworks



@CorvettePassion

CorvettePassion



MidAmericaMotorworks





2900 North Third Street, Effingham, IL 62401 800.500.1500 · Worldwide: 217.540.4200 · FAX: 217.540.4800 www.mamotorworks.com · generalmail@mamotorworks.com @Mid America Motorworks, Inc. All rights reserved.