



**Application:** 1997-2004 C5 Corvette

**Part Includes**

- 1 - Tube of Adhesive Promoter
- 2 - 17" of 1/4" Chrome Trim

## Side Marker Trim



**Tools Needed**



Search: **Trim**  
[www.mamotorworks.com](http://www.mamotorworks.com)

**STEP 1.**

Thoroughly clean the factory plastic side marker with alcohol to remove any and all wax and dirt.

**STEP 2.**

A pencil style adhesive promoter tube has been provided. Snap the tube to release the fluid and then, swipe the outer edge of the 2 side markers.

**STEP 3.**

Peel the release liner from the back of the trim and set it at the very bottom edge of the light lens. Be sure to push the trim against the paint, yet allow it to stick directly to the lens side and work around the lens while peeling the release liner.

**STEP 3.**

After reaching the start point, mark that point by pressing a fingernail into the trim. Cut the trim slightly longer to compensate for shrinkage over time. Apply a tiny drop of instant adhesive to the joint and then buckle the 2 ends together. Press the trim down to achieve a tight butt seam to finish.

**DO NOT GET WET FOR 24 HOURS!**



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**  
 ©Mid America Motorworks, Inc. All rights reserved.