



Application: 2014-2018

Part Includes

- 1- Rubbing alcohol wipe**
- 2- Blackout covers**

Taillight Blackouts



Tools Needed

STEP 1.

Clean each factory taillight with supplied alcohol.

STEP 2.

Peel backing off of the tape from one blackout cover.

STEP 3.

Starting with the top of the cover, simply press the top into place followed by the bottom. You want to push the top in first, then the bottom. Once in place, hold for 10-15 seconds.

STEP 4.

Repeat this process with each of the remaining covers.

STEP 5.

Make sure to allow the 3M VHB adhesive to fully cure, we suggest 10-12 hours before you drive your Corvette.

STEP 6.

Sit back and enjoy your new blacked out look!



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.