



Application: C6 2005-2013



Search: **Exterior Body Trim**
www.mamotorworks.com

Part Includes

- 1 - Stainless Mesh Grille Insert
- 1- Package of Zipties

Front Grille Stainless Steel Mesh



Tools Needed



PROCEDURE:

STEP 1.

Place grille in place for test fitment.

STEP 2.

Make sure the new grille is up against the original grille (fig. 1).

STEP 3.

Leave even space between each end of grille and nose of car.

STEP 4.

Use supplied zip ties to install grille. (fig. 2) Access to back side of original grille is achieved behind lower air dam under front bumper.

STEP 5.

Verify one last time that grille is still centered and level then tighten the zip ties.

STEP 6.

Once ties are snug and grille is attached properly, cut the excess ends off zip ties. Rotate locking head of zip tie behind grille mesh for a more finished look.

NOTE: We recommend 4 zip ties for proper installation, but more can be used if preferred.

Tip: Pre-bend zip ties prior to installation. Start installing zip ties in the center of the grille and work your way to the outside edge.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.