



Application: 1988-1996 Corvette



Search: **Door Sill Protection**
www.mamotorworks.com

Part Includes

- 2-Door Sills
- 6-Flat Head Screws
- 2-Molding Strips
- 10-3/4" Pan Head Replacement Screws

Door Sills



Tools Needed



Your new door sills come to you with a protective liner that you will remove at the end of step 2. This will help produce a nice clean install. Your new door sills are designed to fasten over the two carpet screw areas.

STEP 1.

Remove the two factory screws. Note: These will not be reused. Place your new sill in position over the two holes. Using two of the three screws (provided) for each side, fasten securely. Be sure NOT to OVERTIGHTEN as this will distort the metal. Note: It is important that the flat head screws seat flush in the sills.

STEP 2.

Drill the remaining hole with a 9/64th drill bit and install the final screw. Remove the protective liner.

STEP 3.

You have been provided with two molding strips, use one of them and place it over the screws to finish this part of the installation. DO NOT CLOSE YOUR DOOR.

STEP 4.

In order to create adequate clearance for your new sills it will be necessary to remove the five screws holding your lower carpet to your door panel. You have been provided with 5 replacement screws that will sit deeper into the door panel grommets thus creating adequate clearance.

STEP 5.

Repeat steps one thru four for the opposite sill.

Note: Care must be taken when cleaning your new sills. It is a good idea to lightly dust your sills with a clean soft cloth (or a clean California style duster) first in order to prevent any particles from scratching them. (NOTE: Once this metal is scratched it can not be repaired so please use extra care when cleaning these sills.) Then spray and wipe (using a new clean soft cloth or lint free paper towels) with a good quality streak free glass cleaner.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
 www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.