



**Application:** 2006-2013



Search: **Air Tube Covers**  
[www.mamotorworks.com](http://www.mamotorworks.com)

- 1-2pc Stainless Air Tube Cover
- 1-Pack of Adhesive Promoter
- 2-Self Tapping washer Head Screws
- 2-1" Washer Head Screws
- 2-White Sockets Large
- 2- Large Chrome Cap Covers
- 2-1" Chrome Cap Covers w/Butyl Putty

## Stock Air Tube Cover



### Tools Needed



Your new cover comes to you with a protective liner. Do not remove liner until prompted by the instructions.

#### STEP 1.

Your new two piece cover comes to you pre-shaped however it will be necessary to further shape and form each piece by hand in order to achieve a nice snug contoured fit.

#### STEP 2.

Thoroughly clean the entire air tube with household isopropyl alcohol to remove any dirt and grime. Then swipe the area above the factory emblem with the adhesive promoter provided.

#### STEP 3.

Remove the top of the air tube stud retainer **ONLY NOT THE ENTIRE STUD**. This will expose a small hole at the top of each stud.

#### STEP 4.

Peel the red release liner from the back of the smaller cover and carefully place it onto the factory air tube above the factory emblem. Press firmly at all points to set.

#### STEP 5.

You will notice a small hole on each side of the larger cover towards the front of the car. Fasten the new cover to the air tube using the two self tapping screws provided thru the two white sockets. Be careful not to over tighten! Remove the protective liner and snap on the two large chrome cap covers. Repeat this screw assembly for the top two holes and fasten to the stud hole exposed earlier. Set the two large 1" chrome caps onto the washer head screws, these will have butyl attachment putty and work very well.

#### STEP 6.

Remove protective liner from small section installed in step 3.

**Note:** Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner. Your new cover comes to you with a protective liner. Do not remove liner until prompted by the instructions.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.