



**Application:** 1997-2004 C5 Corvette

**Part Includes**

- 2 - Taillight Blackouts
- 1 - Third Brake Light Blackout

# Corvette Blackout Kit



**Tools Needed**



Search: **Blackout**  
[www.mamotorworks.com](http://www.mamotorworks.com)

**TAILLIGHT BLACKOUTS:**

**NOTE:** It is recommended to install each blackout lens one at a time.

**STEP 1.**

Clean your existing lenses.

**STEP 2.**

Remove mounting screws from the driver side taillight.

**STEP 3.**

While holding the taillight in place, place blackout lens over your existing taillight lens.

**STEP 4.**

Reattach both lenses together to the vehicle, using the original fasteners. Tighten fasteners a little at a time. Do not overtighten.

**STEP 5.**

Repeat for the passenger side.



**THIRD BRAKE LIGHT BLACKOUT:**

**STEP 1.**

Clean your existing lens.

**STEP 2.**

Do a dry run as a practice before peeling off release paper.

**STEP 3.**

Peel off the release paper from the third brake light blackout lens.

**STEP 4.**

Apply adhesive side to your existing third brake light, pressing on outer surface to make sure it is secure.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**  
 ©Mid America Motorworks, Inc. All rights reserved.