



Application: 2014-2019 (All Models)

Part Includes

- 1- Left and Right Side Pair
- 1- Torx wrench

Door Panel and Speaker Protectors



Tools Needed

STEP 1. (DOOR KICKER INSTALLATION)

First, remove the screw with torx wrench provided. When installing door kicker angle the front corner downward then press door kicker against the door panel with one hand near the pocket insert while the other hand guides the bottom edge of the door protector over the bottom of the door as the other hand is pushing insert into the pocket.

NOTE: to prevent unintentional scuffing of the door panel make sure that your fingers are on the edge of the plastic as it slides over the door.



STEP 2.

Line the screw tab recess with that on the door then reinsert the screw and gently screw the screw back in with the torx wrench.

NOTE: Do not cross thread the screw! The screw should screw in easily. Do not over tighten the screw! The screw should be snug.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

STEP 1. (SILL PROTECTOR INSTALLATION)

Start with Sill protector back away from door upright post while hovering over sill.

CAUTION: Be careful that the Sill protector doesn't scuff plastic upright post or sill.

Hook outer edge on painted surface and gently pull Velcro edge of Sill protector over the door sill. Placing the hand underneath the Velcro while going over the sill will help prevent scratching.



STEP 2.

Once the Velcro has cleared the plastic sill align logo window over the logo by gently sliding the sill protector forward. When the sill is located in the proper spot gently press the Velcro into the carpet.

