



Application: 1979-1987

Part Includes

1-C3 Radio Antenna

Power Antenna Replacement



Tools Needed



STEP 1.

Drill out 4 rivets. NOTE: Be careful not to crack housing. If housing is damaged, replace with new housing and cover.

STEP 2.

Remove clips.

STEP 3.

Pry open housing and cover

STEP 4.

Pull and turn cable vertically (90 degrees from spool) at gear connection until hook unlatches from spool.

STEP 5.

Remove seal(s) from cable.

STEP 6.

Unscrew finial from mast

STEP 7.

Pull rod assembly out of tube.

STEP 8.

Latch cable hook of new rod assembly onto spool, making sure its firmly caught



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

STEP 9.

Place seat onto the finial end of the mast assembly.

STEP 10.

Push rod assembly into the tube, until the mast assembly is fully extended.

STEP 11.

Tightly screw the finial back on, making sure not to damage any section of the mast.

STEP 12.

While leaving mast extended, place cable in spool groove and place seat(s) at the end of the tube, then reseal over.

STEP 13.

Secure cover tightly by installing bolts and nuts in the drilled out rivet holes.

STEP 14.

Replace clips on housing and cover.

