



**Application:** 2005-2013 C6 Corvette

**Part Includes**

2 - Tail Lights

## LED Tail Lights



### Tools Needed



Search: **Taillight**

[www.mamotorworks.com](http://www.mamotorworks.com)

#### STEP 1.

Unscrew the two torque screws located at the top of the tail light.

#### STEP 2.

Remove the tail light from the bumper.

#### STEP 3.

Twist off the light bulb socket.

#### STEP 4.

Pull off the tail light from the tail light socket.

#### STEP 5.

Unclip the resistor from the light and remove the plastic cover and stick on the inside tail light housing.

#### STEP 6.

Plug in the new tail light into the light bulb socket making sure the black wire lines up with the black wire on the harness.

#### STEP 7.

Connect the resistor plug into the tail light.

#### STEP 8.

Test all functions making sure they work properly before driving.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.