



Application: 2005–2013 C6 Corvette Base Coupe or Convertible
(Use 658–665) for Z06 or Grand Sport

Part Includes

- 1 – Left rear splash guard
- 1 – Right rear splash guard
- 1 – Left side skirt
- 1 – Right side skirt
- 1 – Installation fastener kit

ZR1 Style Side Skirts



Tools Needed



Search: **Side**
www.mamotorworks.com

NOTE: Allow 30–60 minutes for installation. Removing the wheels may make the installation easier, but is not required.

NOTE: Two people make this installation much smoother.

NOTE: Begin by installing the rear “splash guard” pieces. This is where the alignment begins for the entire installation.

STEP 1.

Install the splash guard piece into the rear wheel well by first removing the screws that attach the inner fender liner. Insert the splash guard between the fender liner and the body of the car. Line up the splash guard with the screw holes, and replace the screws, reattaching the fender liner in the process.



STEP 2.

Position the side skirt to line up with the body lines of your Corvette. A second pair of hands to hold the skirt in position will make the install go much smoother. Attach the rear of the side skirt to the splash guard piece with two screws.

STEP 3.

Double-check the front position of the side skirt. Using pre-drilled holes in the side skirt as a guide, drill one hole in the body of the car near the front end. Attach the skirt to the body with one of the screws.

STEP 4.

Just behind the front wheel, there are a few holes under the car along the edge of the body. Install bolts through the side skirt and the existing holes in the body by hand. It may be necessary to drill your own holes. This is normal. Do not tighten the bolts fully at this time.

STEP 5.

Recheck the position of the side skirt for fit. Using the predrilled holes in the skirt, drill the remaining holes in the body, and attach with screws.

STEP 6.

Finish tightening the bolts, but do not overtighten.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.