



Application: 1984-1996

Part Includes

1 - Component

Pro-Top Interior Cover, Silvertech



Tools Needed



Search: **Protection**
www.mamotorworks.com

INSTALLATION PROCEDURES:

STEP 1.

Unfold the cover and locate the sewn in tab with the word "FRONT" on the black underside.

STEP 2.

Center the cover over the top and windows with the white side upwards. Position the cover UNDER the windshield wipers.

STEP 3.

Attach the Velcro loops through the wipers.

STEP 4.

Pull the elastic straps w/Velcro on each side underneath the outside mirrors. Attach the Velcro.

STEP 5.

Next, pull the rear elastic strap towards the back, behind the rear wheel. Secure the hook on the underside of your vehicle.

STEP 6.

Adjust as you go.

STEP 7.

From the back, pull the Fas-Top tightly, holding the thick strap with the two wooden rods attached.

STEP 8.

Open the gas door, and place the strap inside. You can secure either wooden rod inside, depending on how tight you want your Fas-Top.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

CLEANING INSTRUCTIONS:

The ideal method of cleaning is to wash the cover while it is on the vehicle and allow it to AIR DRY. However, the cover can be washed in a normal household washing machine. Only use COLD WATER and a MILD SOAP, on a GENTLE CYCLE. It is recommended to AIR DRY over a chair, table or clothesline. If dried in a clothes dryer, BE SURE your dryer is set on AIR DRY. **DO NOT USE HEAT.**

IMPORTANT WARNING:

In rare cases when a heavy rain storm is followed by an extreme drop in temperature to below freezing, it is possible for the cover to become frozen to a layer of ice created between the body of the vehicle and the cover. DO NOT attempt to remove the cover immediately. It is recommended to pour WARM WATER over the cover and SLOWLY remove it from the vehicle, carefully inspecting the surface of both the cover and vehicle during the removal process.

Related Parts

604-020 (Interior Cover Deluxe Fas-Top)