



Application: Corvette 2005-2013 C6

Part Includes

1 - Component

Interior Cover, Silvertech



Tools Needed



Search: **Protection**
www.mamotorworks.com

INSTALLATION PROCEDURES:

STEP 1.

Lay cover over top of car.

STEP 2.

Start at front - wrap velcro straps around wiper arms.

STEP 3.

Now attach straps around base of side mirrors.

ON COUPES: STEP 4.

The rear section of Pro-Top, will attach with a strap that reaches from side to side under the glass of rear hatch.

ON CONVERTIBLES: STEP 4.

Or fixed roof cars with trunks, insert long tail of material through trunk, attach to latch, and close trunk.

STEP 5.

After install go back and re-adjust straps.



CLEANING INSTRUCTIONS:

The ideal method of cleaning is to wash the cover while it is on the vehicle and allow it to AIR DRY. However, the cover can be washed in a normal household washing machine. Only use COLD WATER and a MILD SOAP, on a GENTLE CYCLE. It is recommended to AIR DRY over a chair, table or clothesline. If dried in a clothes dryer, BE SURE your dryer is set on AIR DRY. **DO NOT USE HEAT.**

IMPORTANT WARNING:

In rare cases when a heavy rain storm is followed by an extreme drop in temperature to below freezing, it is possible for the cover to become frozen to a layer of ice created between the body of the vehicle and the cover. DO NOT attempt to remove the cover immediately. It is recommended to pour WARM WATER over the cover and SLOWLY remove it from the vehicle, carefully inspecting the surface of both the cover and vehicle during the removal process.

Related Parts

628-569 (C6 Interior Cover)



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.