



Application: 2006-2008 C6 Corvette LS3 & LS7

Part Includes

- 1 - Power Coupler
- 1 - Silicone Band

High Flow Power Coupler



Tools Needed



Search: **Air Intake**
www.mamotorworks.com

STEP 1.

Unplug the breather.

STEP 2.

Unplug the mass airflow sensor.

STEP 3.

Loosen clamps using a standard screwdriver and remove the stock coupler.

STEP 4.

Slip supplied silicone band on the intake.

STEP 5.

Reposition the new High Flow Power Coupler in the same location as the original so the breather hole is correctly aligned. (Use WD40 or similar lubricant if necessary.)

STEP 6.

Reinstall clamps and tighten.

STEP 7.

Plug in breather and mass air flow sensor.

STEP 8.

Enjoy increased performance from your Corvette!



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.