



Application: Corvette 2014-2015



Search: *Underhood Trim*
www.mamotorworks.com

Fuse Box Cover, Polished

Part Includes

- 1 - Stainless fuse box cover
- 1 - Adhesive promoter pack
- 4 - Velcro attachment cookies



Tools Needed



This great looking, all stainless fuse box cover has been designed especially for the C7. It requires no tools to install or to gain access to your fuses. Just follow a few simple steps to change your plain black fuse box into a cool looking custom electrical center.

STEP 1.

Thoroughly clean the top of the factory fuse box with alcohol to remove any and all road grime and dirt. Then swipe the area with adhesive promoter provided.

STEP 2.

Simply peel the release liner from both sides of the cookies and place them at the four corners of the top of the factory fuse box cover. Slide the new cover over the factory fuse box and press firmly over the Velcro cookies areas then remove protective liner.

NOTE: CARE MUST BE TAKEN WHEN CLEANING YOUR COVER. IT IS A GOOD IDEA TO LIGHTLY DUST YOUR COVER WITH A CLEAN SOFT CLOTH FIRST IN ORDER TO PREVENT ANY PARTICLES FROM SCRATCHING IT. THEN WIPE (USING A NEW CLEAN SOFT CLOTH) WITH A GOOD QUALITY STREAK FREE GLASS CLEANER. SEE ENCLOSED CARE SHEET.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.