



Application: Corvette 2014-2015

Part Includes

- 1 - Stainless Fuse Box Cover
- 1 - Adhesive Promoter Pack
- 4 - Velcro Attachment Cookies

Master Cylinder Cover, Polished



Tools Needed



Search: **Underhood**
www.mamotorworks.com

STEP 1.

Thoroughly clean the top of the factory fuse box with alcohol to remove any and all road grime and dirt. Then swipe the area with the adhesive promoter provided.

STEP 2.

You have been supplied with four Velcro attachment cookies. Simply peel the release liner from both sides of the cookies and place them at the four corners of the top of the factory fuse box cover. Then simply slide the new cover over the factory fuse box and press firmly over the Velcro cookies areas then remove protective liner.

NOTE: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a clean soft cloth) with a good quality streak free glass cleaner. See enclosed care sheet.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.