



Application: Corvette 2014-2015



Search: **Underhood Trim**
www.mamotorworks.com

Master Cylinder Cover, Polished w/ Ribbed Slots

Part Includes

- 1 - Stainless cylinder cover w/ Velcro attachment cookie
- 1 - Adhesive promoter packet
- 1 - 3/4 chrome cap cover w/ Velcro attachment cookie



Tools Needed



Your new accessory comes to you with a clear protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed installation.

This cover is a nice way to just about instantly transform your stock master cylinder reservoir into a custom accessory which will look great in any C7 Corvette.

STEP 1.

Thoroughly clean the top surface of the reservoir and the fluid cap with household rubbing alcohol to remove any road grime and dirt. Swipe the areas with the adhesive promoter provided. Remove the factory fluid cap.

STEP 2.

Remove the Velcro attachment cookie half and install it directly to the prepared surface of the reservoir.

STEP 3.

Place the new cover over the reservoir pressing down gently to set in position. Replace the factory fluid cap and remove the protective liner.

STEP 4.

You have been provided with a chrome cap cover that also has a Velcro attachment cookie. Simply remove the cookie half and mount it to the factory fluid cap pressing firmly to set. Press the chrome cap in place.

NOTE: CARE MUST BE TAKEN WHEN CLEANING YOUR COVER. IT IS A GOOD IDEA TO LIGHTLY DUST YOUR COVER WITH A CLEAN SOFT CLOTH FIRST IN ORDER TO PREVENT ANY PARTICLES FROM SCRATCHING IT. WIPE (USING A NEW CLEAN SOFT CLOTH) WITH A GOOD QUALITY STREAK FREE GLASS CLEANER. SEE ENCLOSED CARE SHEET.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.