

C7 OR C8 MAP TINT



CAUTION: DO NOT REMOVE THE LENS FROM THE MAP HOUSING!! You will have to drop part of the headliner to re-install the lens if you do!




One extra sheet is provided in case you make mistakes. Remove the adhesive backing by placing a piece of scotch tape on each side then pull off the backing with the tape. Carefully lay the film over the light making sure the entire light is covered.



Start in the middle of the lens and work the film out toward the edges making sure to eliminate bubbles and wrinkles. It helps to lift the film with one hand and press the film outward with the other. You can use a credit card as a squeegee to press out any bubbles or creases.



Work the tint into the edges of the lens around the front side of the lens first. Next move to the rear of the lens behind the button. Lift the tint while working it onto the lens behind and around the button. It tough to get the back of the lens covered without 1 small crease but where its at it doesn't show easily.



Using a new razor blade, very carefully trim the excess tint from the lens by cutting against the lens not the fabric headliner. Go slow and be careful. Use your fingernail to press the tint into the edges.



Trim around the button being very careful on the corners. Use your fingernails to press the tint into the crease.



Remove the tint from the button. If you have to re-do the tint, clean the adhesive residue with wax or grease remover or window cleaner before re applying the tint. Go back and press the tint into the corners and creases one last time.