Protect your C8 Corvette's Interior Door Sill



To install the Sill protector line the back edge up with the parting line on the plastic portion of the door sill. Hook the short edge on the painted portion of the door sill with hands on the Velcro gently pull sill protector over door sill. Be mindful of the front pillar as not to scuff during installation. Press the Velcro into the carpet.



