



Application: Corvette 1963-1967, 1968-1982

Part Includes

1 - Component

Speaker Bar, Bass Ported



Tools Needed



Search: *Radios, Antennas & Cameras*
www.mamotorworks.com

Determine which installation configuration is proper for your car. DO NOT cut center panel (D) until installation is complete.

STEP 1.

Put spanner bars (C) into speaker panels (A). For an easier fit, the space between the speaker panels should be less than the inside dimensions of your installation.

STEP 2.

Place unit in position. Extend Speaker panels (A) outward for a firm fit and tighten set screws (B).

OPTIONAL (HIGHLY RECOMMENDED)

Use self drilling screws (included) to secure ends of speaker panels. **CAUTION: DRILL THROUGH CARPET AT YOUR OWN RISK.**

STEP 3.

Route speaker wire to sound source and check for proper operation.

STEP 4.

Hold the center panel (D) between speaker panels with logo centered and mark ends. Cut to fit with a sharp razor blade knife.

STEP 5.

Press center panel (D) into place and firmly press bass port covers (F) into place.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

