



**Application:** 1968-1982

**Part Includes**

1 - Component

## Headlight & Wiper Door Vacuum Relay Valve



### Tools Needed



Search: **Windshield Wiper System**  
[www.mamotorworks.com](http://www.mamotorworks.com)

### STEP 1.

Find the location for the headlight relay under the hood between the headlights. The wiper door vacuum relay location is under the rear right-hand fender well or the left side of the firewall.

### STEP 2.

Mark the placement of the hoses so they can be re-connected later. The original hoses had striping to match the color coded dots on the original relay. The replacement valve is initialed and color-coded for ease of hose re-installation.

### STEP 3.

Unbolt the old relay and replace it with the new one. Re-connect the hoses in their proper positions. An extra filter has been provided as a spare. These filters can also be cleaned by using soap and water only.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.