



Application: 1968-1982

Part Includes

1 - Component

Power Window Switch



Tools Needed



Search: *Electrical System*
www.mamotorworks.com

FOR 1968-76 CORVETTES:

STEP 1.

Remove Emergency Brake Console. Consult GM, Haynes, or Chilton Service Manual for assistance.

STEP 2.

Gently disconnect wiring harness(es) from back of power window switch(es).

STEP 3.

Note terminal post position on switch(es) for proper reinstallation. Remove retainer(s) holding switch(es) in place. Install new switch(es).

STEP 4.

Reinstall retainer(s), and wiring harness(es).

STEP 5.

Test function of new switch(es) before reinstalling console.

FOR 1977-82 CORVETTES:

STEP 1.

Remove center shift plates. Consult GM, Haynes, or Chilton Service Manual for assistance.

STEP 2.

Gently remove wiring harness(es) from back of power window switch(es).

STEP 3.

Lay shift plates face-down on protected surface. Note terminal post position on switch(es) for proper reinstallation.

STEP 4.

Remove screws holding switch(es) in place and replace defective switch(es).

STEP 5.

Reconnect all harnesses and test function of new switch(es) before reinstalling shift plates.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.