



Application: Corvette 1978-1982

Part Includes

1 - Sun Shade

Sun Shade



Tools Needed



Search: **Vehicle Protection**
www.mamotorworks.com

DIRECTIONS FOR SAFE AND PROPER APPLICATION

Step 1.

Install between temperatures of 65 and 90 degrees F, out of direct sunlight or excessive heat.

STEP 2.

Remove roof panel. For best adhesion, be sure PANEL(S) and FILM are free from debris, lint and dust. It is recommended that a cleaning solution be made of 2 tablespoons of baby shampoo such as "NO TEARS" per gallon of warm water. A solution of 1 part vinegar to 2 parts water can also be used to clean both surfaces. Dry surfaces with a dust free and silicon free cloth. Silicones and similar aerosols affect the static cling properties of the film. It is imperative that the work environment be absolutely free from these contaminants as well as air-born particles of dust that may adhere to the glass surfaces or to the static side of the film. Special care should be taken when cleaning the glass of stubborn deposits such as tobacco smoke residue.

STEP 3.

Unroll Sun Shade. Some of our Sun Shade material may have a clear backing that must be removed before use. You can determine this by checking to see if the holes in the Sun Shade are open (no backing) or sealed (has clear backing - Fig.1). It is always the glossy side of the material that goes onto the surface of the glass. Position the shade evenly on the panel, using the palm of your hand start in the middle and work to the edges. A (SOFT) rubber squeegee is also good for smoothing out the air bubbles. If bubbles occur, peel back the closest edge to the bubble to release air and smooth back to edge as before. If film appears to have lost its static properties, after cleaning steps have been followed, tumble film and a damp cloth in the clothes dryer on (LOW) heat setting for about 2 minutes. Be careful not to overheat. If wrinkles occur, the material can be ironed on low heat protected by a thin damp cotton towel.

STEP 4.

To remove Sun Shade, simply peel back one corner, then pull gently off of panel.

STEP 5.

When not in use, roll Sun Shade and store out of direct light.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.