



Application: 1968-1976

Part Includes

1 - Component

Corvette Switch Windsheild Wiper



Tools Needed



Search: *Electrical System*
www.mamotorworks.com

STEP 1.

Remove center gauge cluster that contains wiper switch. Consult GM, Chilton, or Haynes Service Manual for removal process.

STEP 2.

Disconnect wiring harness to back of wiper switch.

STEP 3.

Remove control knob on switch and retain. Remove two mounting screws from back of switch. Remove switch.

STEP 4.

Remove black sleeve from the control lever of the old switch, and place on new switch.

STEP 5.

Install new switch. Test function of switch before reinstalling center gauge cluster.

STEP 6.

SPECIAL NOTE: Gauge cluster bezel must have ground wire attached to test switch.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.