



**Application:** 1970-1972 Corvette

**Part Includes**

1 - Pair of Stainless Steel Exhaust Tips

## Stainless Steel Exhaust Extensions



### Tools Needed



Search: **Exhaust Systems**  
[www.mamotorworks.com](http://www.mamotorworks.com)

These extensions are to be fitted over the outside of your stock muffler outlets.

### STEP 1.

Before installing, clean your muffler outlet tips of road dirt, oil, debris, etc. Slide exhaust tip over the outlet end of your muffler until you find the position that looks best to you. It is suggested that the end of the tip should not extend too far past your rear bumper fascia.

### STEP 2.

Fasten the exhaust tip to your muffler tip using 2 1/4" muffler clamps. Before tightening clamps on both mufflers, make sure that both tips are aligned with each other for best looks. Then tighten clamps on both.

### STEP 3.

Check tightness on both clamps periodically to assure a tight fit to avoid rattles or loss of tips.

### STEP 4.

Clean the tips during car washes. Should the finish become dull, use any good stainless polish to return the luster.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.