



*Part Number*

**600-860**

**600-862**

**Application:** 1975–1979 Corvette, 1980–1982 Corvette



Search: **Body Panels – Fiberglass**  
[www.mamotorworks.com](http://www.mamotorworks.com)

## Collector Rear Skirt

**Part Includes**

2 – Rear Skirts



### Tools Needed



**NOTE:** To ensure proper installation, please fit all parts before drilling, sanding or painting. Part can not be returned after drilling, sanding or painting has occurred.

#### STEP 1.

Tape off area around the ground effects. We recommend using 2 inch masking tape.

#### STEP 2.

On the ground effects, put a grease pencil mark on the top edge of the skirt. This enables you to mark the holes for step 3.

#### STEP 3.

Hold rear ground effects in place, holding forward part of skirt against fenderwell and rear part against license plate surround.

#### STEP 4.

After positioned correctly, using a grease pencil, draw a line on the bumper along the top of the skirt, and mark bolt hole lines.

#### STEP 5.

Remove skirt from bumper. Using a 3/16 inch drill bit, drill the holes in the skirt where indented.

#### STEP 6.

From holes (using a grease pencil), mark out towards visible face of the skirt. After the hole positions are located, hold skirt to bumper.

#### STEP 7.

Using a grease pencil, mark the locations of the holes in the skirt on the bumper and quarter panel. Then measure the distance of the holes from the tip edge of the skirt. Take these measurements and mark the locations of the holes on the bumper down from the line drawn on the bumper.

#### STEP 8.

At these locations, using a 3/16 inch drill bit, drill holes in the bumper and the quarter panel.

#### STEP 9.

Repeat these steps for both sides.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.



## **Description** (cont.)

**STEP 10.**

Check for proper fit before painting by loosely installing pieces.

**STEP 11.**

Remove rear skirts, prep, paint, and buff.

**STEP 12.**

Reinstall rear skirts.