



**Application:** 1975-1982 Corvette



Search: *Body Panels - Fiberglass*  
[www.mamotorworks.com](http://www.mamotorworks.com)

**Part Includes**  
2 - Side Skirts

## Collector Side Skirts



### Tools Needed



**Note:** To ensure proper installation, please fit all parts before drilling, sanding or painting. Part cannot be returned after drilling, sanding, or painting has occurred.

### DIRECTIONS FOR SAFE AND PROPER APPLICATION

**STEP 1.**

Remove factory rocker molding.

**STEP 2.**

Hold ground effects in place to ensure proper fit and center before drilling any holes.

**STEP 3.**

Hold ground effects in place and mark the 4 holes to be drilled. Two in the rear wheel well and two in the front wheel well. While you have the ground effects in position, mark the 4 holes to be drilled in door jam.

**STEP 4.**

Using a 3/16 inch drill bit, drill the 4 holes on the face of the ground effects.

**STEP 5.**

With the same 3/16 inch drill bit, drill two holes in the front of the ground effects.

**STEP 6.**

Install the ground effects loosely to check fit once more.

**STEP 7.**

Remove kit to prep, paint, and buff.

**STEP 8.**

Reinstall.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401  
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800  
[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)  
©Mid America Motorworks, Inc. All rights reserved.