



**Application:** 1978-1982 Corvette

**Part Includes**

- 2 - Liner Panels
- 8 - Screws
- 4" Rubber Hose

# T-Top Headliners



**Tools Needed**



Search: *Convertible, Removable T-Tops*  
[www.mamotorworks.com](http://www.mamotorworks.com)

**NOTE:** To ensure proper installation, please fit all paers before drilling, sanding, or painting. Part cannot be returned after drilling, sanding, or painting has occurred.

**DIRECTIONS FOR SAFE AND PROPER APPLICATION**

**STEP 1.**

Lay T-top on towel facing down.

**STEP 2.**

Remove old T-top liner.

**STEP 3.**

Remove "Velcro" looking round fasteners at corners of the top. (Diagram A)

**STEP 4.**

Trim the included rubber hose to 1/2 inch lengths for proper installation.

**STEP 5.**

Push screws through liner and put rubber spaces on back side.

Do this to the four corners. ( Diagram B)

**STEP 6.**

Lay new liner on T-top and fasten screws. Do not over tighten the screws.



**Diagram A**



**Diagram B**



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.