



**Application:** Corvette 1978-1982



Search: *Interior Trim, Door Panels, Sunvisors*  
[www.mamotorworks.com](http://www.mamotorworks.com)

**Part Includes**

- 1 - Screw
- 1 - Repair Sleeve

# Arm Rest Repair Kit



**Tools Needed**



**INSTALLATION:**

**STEP 1.**

Remove arm rest screw from door panel.

**STEP 2.**

For best results, replace any plastic remaining on the screw back into the arm rest.

**STEP 3**

Install repair fitting sleeve, washer side first and open end facing out, making sure it is seated as flush as possible in the arm rest.

**STEP 4.**

Drill a 1/8" hole straight up through side hole (A) and into the thickest part of the arm rest, making sure not to drill all the way through the arm rest.

**STEP 5.**

Install the smaller screw into the drilled hole to secure repair fitting sleeve to the arm rest.

**STEP 6.**

Install the large screw through the fitting and into the door. Do not overtighten.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401  
 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800  
[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)  
 ©Mid America Motorworks, Inc. All rights reserved.