



Application: 1978-2004



Search: *Radios, Antennas & Cameras*
www.mamotorworks.com

Part Includes

1 - Component

Insulation Power Antenna Heat Shield



Tools Needed

STEP 1.

It may be necessary to remove or loosen the left hand muffler to gain access to the antenna.

STEP 2.

Remove screw at bottom of the antenna.

STEP 3.

Slide Heat Shield under and around antenna as in diagram.

STEP 4.

Re-install screw (you will need to pierce a hole in the Heat Shield to re-install the screw).

STEP 5.

Press Velcro tabs together.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.