



Application: 1984-1988

Part Includes

- 1 - bulb kit
- 1 - 4" wooden dowel
- 1 - 3" hose

Gauge Cluster Light Bulb Kit



Tools Needed



Search: *Lighting, Exterior & Interior*
www.mamotorworks.com

STEP 1.

Remove the headlight switch knob by pushing a small screwdriver rearward behind the knob. The shaft will stay in the headlight switch.

STEP 2.

Remove the three Phillips screws holding the cluster bezel to the left outer instrument panel.

STEP 3.

Remove the Phillips screws holding the right side of the cluster bezel to the instrument panel and set the bezel to the side.

STEP 4.

Unsnap the shiny metal cover over the bulbs. Change all four bulbs while you have the instrument panel apart.

CAUTION: These bulbs are gas filled so do not break them on removal or assembly.

STEP 5.

Carefully remove each Halogen bulb with needle-nose pliers.

NOTE: It is recommended that you avoid touching halogen bulbs with your fingers, and use a soft clean cloth while handling them. Always wipe off each new bulb with a clean soft cloth to remove any dirt or oil from fingerprints before installation.

STEP 6.

To install each new bulb, place it into the tip of the 3 inch hose included in kit. Insert the 4 inch wooden dowel in the other end of the hose. Insert the bulb into the cluster's socket. While holding the hose, seat the bulb into the socket by carefully pressing on the end of the dowel. To remove the hose from the bulb, hold the dowel against the bulb and pull the hose outward. If necessary, use the tip of your finger to completely push the bulb into the socket, and then take a soft cloth and remove your fingerprint from the tip of the bulb. The oil from your fingers can cause bulbs to fail prematurely.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

STEP 7.

Reinstall cluster bezel, and headlight switch knob.

