



Application: 1984-1989 Corvette



Search: *Interior Trim, Door Panels, Sunvisors*
www.mamotorworks.com

Part Includes

2 - Metal Door Pulls

Armrest Filler Pull Savers



Tools Needed



STEP 1.

Lower the window on the door you are repairing.

STEP 2.

Remove the two phillips screws in the armrest/grab handle cup.

STEP 3.

Remove the stock plastic armrest/grab handle cup.

STEP 4.

Slide the new Armrest Saver into the door panel with a scooping motion, opposite from above removal. The Armrest Saver will be installed with the "taller" side toward the inside of the car.

STEP 5.

Replace screws. Note: Depending on the severity of the damage to the armrest, you may have to push the armrest outward to match up the door panel to the armrest.

STEP 6.

Repeat on opposite door.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.