



**Application:** 1984-1990 Corvette

**Part Includes**

1 - Pair

## C4 Front Turn Signal Protective Shield



### Tools Needed



Search: **Vehicle Protection**  
[www.mamotorworks.com](http://www.mamotorworks.com)

### PREPARATION

Preparation and installation of Protective Shields requires temperature to be above 50°F. **DO NOT WASH THE VEHICLE FOR 48 HOURS AFTER APPLICATION OF PROTECTORS TO ALLOW THE GLUE TO SET.**

#### STEP 1.

Thoroughly clean the lamp. Ensure that all road film is cleaned off.

#### STEP 2.

Make sure your hands are clean and dry the lamp with a lint-free cloth.

#### STEP 3.

Warm the protectors with a hair dryer or your car's heater, making the protector more pliable and easy to install.

### INSTALLATION

**NOTE: OUR PROTECTORS HAVE BEEN CUSTOM CUT TO FIT AROUND THE ALIGNMENT OF LIGHT LENSE. BE SURE TO POSITION THE PROTECTOR CORRECTLY BEFORE REMOVING THE BACKING PAPER.**

#### STEP 1.

Peel off backing paper from half of one of the protectors.

#### STEP 2.

Start at one edge of the turn signal, using moderate pressure, press the protector in a sweeping motion across the turn signal with one hand. Remove the remaining backing paper with the other hand and repeat the process for the remaining half.

#### STEP 3.

Press out any large air bubbles to the edges of the lens. Small air bubbles will eventually disappear with use.

#### STEP 4.

Repeat steps 1-3 for each bulb.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.