

# Application: Corvette 1984–1996



Search: Weatherstripping and Body Seals

www.mamotorworks.com

**Door Sill Auxiliary Seals** 





### STEP 1.

Clean door lip surface with rubbing alcohol. DO NOT SMOKE OR HAVE SPARKS OR OPEN FLAME NEAR WORK AREA!

## STEP 2.

Remove the adhesive strip attached to the Door Sill Seal.

#### STEP 3.

Carefully position Door Sill Seal at the bottom of the door lip. For best seal, make sure that the strip is flush with bottom of door (see item #1).

#### STEP 4.

When complete, press on door seal to make sure adhesive has bonded with your door.



**ATTACHES TO BOTTOM OF** 

**TEM #1** 

f Mamotorworks

@CorvettePassion

CorvettePassion

MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.

.....

# **INSTRUCTION SHEET**

# Part Number



Part Includes