

## **INSTRUCTION SHEET**

**Part Number** 

612-019

**Part Includes** 

1 - Pair of Stretch Fit Mirror Masks

## **Mirror Covers**



**Tools Needed** 

**Application:** Corvette 1984–1996, 1997–2004, 2005–2013



## STEP 1.

Stretch Fit Mirror Cover (MC) over the side mirror. NOTE: This is a tight fit, but the material will stretch to allow the cover to pass over the housing.

## STEP 2.

Arrange the material adjusting as necessary to get the mirror cover to fit smoothly on the housing. The material can be installed behind the glass mirror by wedging the material through the gap between the mirror glass and the mirror housing using a credit card.

CAUTION: It may be necessary to use the credit card when removing the mirror covers if the material hangs up on the retaining clips inside the mirror housing.





Mamotorworks



@CorvettePassion



Mid America Motor works





2900 North Third Street, Effingham, IL 62401 800.500.1500 · Worldwide: 217.540.4200 · FAX: 217.540.4800 www.mamotorworks.com · generalmail@mamotorworks.com @Mid America Motorworks, Inc. All rights reserved.