



**Application:** Corvette 1985-1991

**Part Includes**

- 1 - Set of ZR-1 Style Tips
- 1 - Bolt Kit
- 1 - Shim Kit

## ZR-1 Style Exhaust Tips



**Tools Needed**



Search: **Exhaust Systems**  
[www.mamotorworks.com](http://www.mamotorworks.com)

**STEP 1.**

Slide extension over stock muffler pipe end to check for fit. Some replacement mufflers may differ in diameters or angles, so some fit corrections may be necessary before final installation.

**STEP 2.**

The fit of the extension over the muffler tip should be snug, but not loose. Check the angle of the muffler tip and adjust the muffler tip for the look you want. Muffler tips may be adjusted using a long piece of pipe that has a slightly wider inner diameter than the outer diameter or your muffler tip. Place the pipe "over" the outside of your muffler tip and use a little force to position it where you want.

**STEP 3.**

Align each muffler tip so that all exhaust tips line up in height and spacing. The tips should not extend out too far past your bumper and should be about 1/2"-3/4" below the bottom lip of the bumper. Use the included shims to make any final adjustment in aligning the tips.

**STEP 4.**

Once final alignment is complete, fasten the tips onto your muffler tips with the enclosed 1/4" bolt, washer and lock nuts. Check fit and tightness of bolt periodically to avoid loss or rattle.

**STEP 5.**

Clean tips during regular car washings.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**  
 ©Mid America Motorworks, Inc. All rights reserved.