



Application: 1990-1996 Corvette

Part Includes

- 1 - Cold Air Induction Snorkel w/ Filters
- 2 - Snap Clamps
- 1 - 7" Piece of Hose
- 1 - Nylon Hose Barb
- 2 - Standoff Spacers

Cold Air Induction System



Tools Needed



Search: **Engine Components**
www.mamotorworks.com

STEP 1.

Begin by removing the factory airbox with lid and filter from vehicle. Separate the oval end of rubber bellows from it, and remove the two outer hold down screws. Save the two screws for mounting the new induction tube. Also remove the A.I.R. Pump supply hose from airbox and save the snap clamp.

STEP 2.

Position new triple induction tube in place and secure loosely with the two hold down screw removed earlier with the stand off spacers provided on them. Tabs on induction tube should fit flat against threaded inserts in radiator shroud

STEP 3.

Slide the nylon hose barb, 7" piece of hose, and the two new plastic snap clamps, extend the factory A.I.R. pump supply hose so it reaches the tube stub on the induction tubes. Tighten all three snap clamps.

STEP 4.

Tighten the two hold down screws, and position each of the high flow filters so that they lay flat against the fiberglass radiator shroud. (NOTE: the slight angle on each filter's rubber inlet flange for adjustability.) Tighten band clamps on each filter. Installation is now complete.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.