



*Part Number*

**600-754**

**600-756**

**600-758**

**Application:** 1995-1996 Corvette



Search: **Body Trim, Bumper & Grilles**  
[www.mamotorworks.com](http://www.mamotorworks.com)

## Acrylic Louver Accents

**Part Includes**

1 - Decal Kit



### Tools Needed



**BEFORE APPLYING ANY PRESSURE TO THE DECAL, BE SURE YOUR APPLICATION IS STRAIGHT.**

#### STEP 1.

Make sure that the side port louver surface is clear of any wax, using a rubbing alcohol prep pad or similar means to promote good adhesion.

#### STEP 2.

Use belt line, or top of the louver, as a straight line reference. (The decals are designed to remain straight, not angled down.) Starting at the front of the side port impression, peel back 3"-4" of backing paper from the decal. Begin with the shortest decal (at the top).

#### STEP 3.

Slowly apply the decal toward the rear of the car peeling more of the paper at the same time. If the application gets wrinkled, with very little pressure, slowly pull the decal back up and start again.

#### STEP 4.

When the decal is in place, use a moistened washcloth and apply firm pressure, especially to the perimeter of the decal sealing out the elements.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.