



Application: 1997-2004

Part Includes

1 - Component

Air Foil, Throttle Body Flow Booster



Tools Needed



Search: **Engine Components**
www.mamotorworks.com

STEP 1.

Make sure engine is cool.

STEP 2.

Use screwdriver to loosen clamps on breather tube attached to front of throttle body. Pull tube forward or to the side to allow access to throttle Body inlet. (Illustration A.)



STEP 3.

Insert Air Foil with white index mark at top center of throttle body. (Illustration B.)

STEP 4.

Clean outer leading edge of throttle body inlet for proper tape adhesion. Apply tape completely around opening with 1/4" overlap of leading edge.

Wrap tape over edge to hold Air Foil in place & to seal gap between Air Foil and throttle body lip. (Illustrations C and D)



STEP 5.

Re-install breather tube. (Illustration E)

STEP 6.

Tighten screws.

STEP 7.

Test drive.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.