

Application: 1997–2013



Search: Weatherstripping and Body Seals

www.mamotorworks.com

Corvette Door Sills





STEP 1.

Clean door lip surface with rubbing alcohol. CAUTION! DO NOT SMOKE OR HAVE SPARKS OR OPEN FLAME NEAR WORK AREA.

STEP 2.

Remove the adhesive strip attached to the Door Sill Seal.

STEP 3.

Carefully position Door Sill Seal at the bottom of the door lip. For best seal, make sure that the strip is flush with bottom of door (see item #1).

STEP 4.

When complete, press on door seal to make sure adhesive has bonded with your door.

STEP 4.

You may cut strip to desired length or leave full length for maximum protection.



INSTRUCTION SHEET

Part Number



Part Includes

2 – Sill Seals



Mamotorworks

@CorvettePassion

MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.

.....

CorvettePassion