



**Application:** 1998-2002

**Part Includes**

1 - Component

# Divert-A-Breeze



## Tools Needed



Search: **Windscreens**  
[www.mamotorworks.com](http://www.mamotorworks.com)

### PREPARATION:

**Important Note:** THE DIVERT-A-BREEZE WILL ONLY WORK ON SPORT SEATS, WHICH FEATURE A HOLE BETWEEN THE SEAT BACK AND HEADREST. To make room for installation, move seats and adjust backs forward. No preparation is necessary for the seat surface.

### INSTALLATION:

#### STEP 1.

Lay out the Divert-A-Breeze with the back facing up (this is the side with the slotted openings). Close the CENTER SECTION ONLY by attaching the Velcro pieces, as shown in Illustration (A).



#### STEP 2.

Slide the driver's side over the top of the seat and slip the seat back release lever through the slot opening, as shown in Illustration (B). Repeat on the passenger side.



#### STEP 3.

With one hand on the front Velcro flap and one hand on the rear Velcro flap, pull the Divert-A-Breeze down until its angled edges match the angled edges of the seam on the seat, Illustration (C-1). At the same time, make sure to line up the double stitching of the Divert-A-Breeze with the double stitching of the seat back. **NOTE:** It helps to have another person at this stage, so that one can pull the BACK Velcro flap down, while the other pulls the FRONT Velcro flap down.



#### STEP 4.

Fold the back Velcro flap into the hole in the backrest, Illustration (C-2). Then overlap it with the front Velcro flap (C-3) to secure the driver's side of the Divert-A-Breeze.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**  
©Mid America Motorworks, Inc. All rights reserved.



## Description (cont.)

### STEP 5.

Re-adjustment may be necessary if the flaps are not pulled down tight enough to match up the angled seams or to smooth out buckles in the front flap, Illustration (D). Repeat steps 1 through 5 for the passenger side.

C-2



C-3



D

