

**Application:** Corvette 2000-2004

## **INSTRUCTION SHEET**

**Part Number** 

602-262

**Part Includes** 

1 - Scratch Guards

# **Door Handle Scratch Guards**



**Tools Needed** 



#### **DIRECTIONS FOR SAFE AND PROPER APPLICATION**

#### STEP 1.

Clean and dry area where guards are to be installed with plain water and a dry towel. Avoid using cleaners which contain anti-static components as they will keep scratch guards from adhering. Package contains one pair.

#### STEP 2.

Peel apart the guards (they are stuck together for protection).

### STEP 3.

Guards can be removed and reinstalled as often as you wish, as they are static cling.







Mamotorworks




@CorvettePassion





MidAmericaMotorworks



2900 North Third Street, Effingham, IL 62401 800.500.1500 · Worldwide: 217.540.4200 · FAX: 217.540.4800 www.mamotorworks.com · generalmail@mamotorworks.com @Mid America Motorworks, Inc. All rights reserved.