



Application: 1968-1977 C3 Corvette



Search: **Convertible, Removable & T-Tops**
www.mamotorworks.com

Part Includes

1 - Headliner Pad

T-Top Headliner Pad, LH



Tools Needed



STEP 1.

Inspect the T-top you have received. It should be the correct color and side for your Corvette.

STEP 2.

With the Phillips screwdriver, remove the two screws that go through the retaining clips on the pad and into the actual top. One screw is located between the latch mechanisms and the other is directly opposite. The screws may be partially hidden by the weatherstrip.

STEP 3.

With the screws removed, gently pry the original pad from the top with your hands. It is held in place around its perimeter with plastic fasteners and will separate easily.

STEP 4.

Remove the retaining clips from the original pad by placing the tip of a straight bladed screwdriver between the clip and the pad and pushing the clip away from the center of the pad.

STEP 5.

Replace the retaining clips on your new pad in the slots provided by inserting the edge of the clip under the plastic backing and pushing the clip toward the center of the pad.

STEP 6.

Place the new pad in position on the T-top. Press down firmly around the perimeter of the pad to secure the plastic fasteners on the pad to those on the top.

STEP 7.

Replace two screws in the retaining clip on each side of the pad.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.