



**Application:** 1984-1986 Corvette

**Part Includes**

1 - Power Window Ribbon

## Power Window Ribbon



### Tools Needed



Search: *Electrical System*  
[www.mamotorworks.com](http://www.mamotorworks.com)

### REMOVAL

#### STEP 1.

Lower the glass approximately 4-6 inches from the top.

#### STEP 2.

Disconnect negative battery cable.

#### STEP 3.

Remove the armrest, speaker grille cover, and finally the door panel.

#### STEP 4.

Disconnect wiring harness connectors at the rear of the inner mounting plate.

#### STEP 5.

Mark the position of the guide bolts and remove the mounting plate-to-door screws.

#### STEP 6.

Remove the bolts holding the motor to the plate, the guide to the plate and the guide to the door. Remove the guide.

#### STEP 7.

Disconnect the rods at the remote lock and lock actuator.

#### STEP 8.

Push the mounting plate down and pull the top out to gain access to the remote rod clip. Remove the remote rod from the plastic guide.

#### STEP 9.

Disconnect the window regulator motor electrical connector.

#### STEP 10.

Pull the inner mounting plate out of the door and let it hang from the lock rod at the rear of the door.

#### STEP 11.

Remove the two weatherstrip screws at the window opening in the door.

#### STEP 12.

Mark the position of the glass stop bracket and remove the bracket.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**

**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**

**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**

©Mid America Motorworks, Inc. All rights reserved.



## Description (cont.)

### STEP 13.

Loosen the anti-rattle pads and move them as necessary to allow the glass to be removed.

### STEP 14.

Remove the regulator-to-glass nuts and pull the glass up through the top of the door.

### STEP 15.

Remove the five regulator bolts and remove the regulator.

### REPLACEMENT

#### STEP 1.

With regulator assembly removed from door, drill out rivets (Item 1). With Allen wrench, remove ribbon bolt (Item 2).

#### STEP 2.

Pull window ribbon (Item 4) toward top of track and remove.

#### STEP 3.

Apply lubricant, preferably white lithium grease, to the new ribbon and track.

#### STEP 4.

Slide new ribbon onto track (Item 3).

#### STEP 5.

Using extreme caution, support regulator assembly so that moving ribbon will not cause damage or injury.

**TEMPORARILY RECONNECT NEGATIVE BATTERY CABLE FOR THIS STEP ONLY.** Connect the wiring harness connector (removed in Step 4 of "REMOVAL" process) to the power window motor. Activate power window motor to accept new ribbon. Run ribbon through motor to align with window support mounting bolt (Item 2).

#### STEP 6.

**DISCONNECT NEGATIVE BATTERY CABLE.** To complete this procedure, the battery must remain disconnected to prevent damage to switches, fuses, etc. resulting from metal to metal contact inside the door during the reinstallation process.

#### STEP 7.

Using a small nut and bolt or pop rivet, attach ribbon track (Item 3) to track support (Item 5).

#### STEP 8.

Reinstall all door components by reversing "REMOVAL" process.

