



Application: 1997-2000 C5 Corvette

Part Includes

- 4 - Exhaust Tips with Mounting Clips
- 8 - Optional Stainless Steel Screws

Polished Stainless Steel Exhaust Tips



Tools Needed



Search: **Exhaust Systems**
www.mamotorworks.com

VERY IMPORTANT

Prior to installation, park vehicle on level surface and set parking brake.
MAKE CERTAIN THE EXHAUST SYSTEM IS COOL!

DIRECTIONS FOR SAFE AND PROPER APPLICATION

STEP 1.

With the sight holes facing downward, position a new exhaust tip over an existing muffler outlet.

STEP 2.

Each new exhaust tip contains four spring steel mounting clips welded inside. These Clips are made from spring steel and are very "stout". You will need to use heavily pressured taps with a rubber mallet or the heel of your hand to get the clips "started" on the existing tip. It is most effective to use a dowel directly against each individual clip. Alternate from one clip to another to install evenly. Be sure to seat the new tips securely until the clips are flush with the original tips. Repeat steps 1 & 2 with remaining tips.

STEP 3.

Check alignment of new tips, adjust as needed.

DETAILING HINTS: Slanting the point of the tips upward toward the front of the car will prevent water welling and internal staining of the tip over time. After the tips are mounted, to help mask the mounting clips from view, spray a high-temp black paint through the new tip. Lightly coat each clip and let dry. Repeat as necessary. For cleaning and maintaining the high luster of your new exhaust tips, use mild detergent and warm water for cleaning. Use low abrasive metal polish for protection and removal of light scratches.

OPTIONAL MOUNTING SCREWS:

Although we've found that the heavy duty clips welded to your new Stainless Steel Exhaust Tips are substantial enough for a secure, no modification mount, we include with your new exhaust tips you'll find an optional set of 8 stainless steel mounting screws. To use these screws, drill 1/8" pilot holes through the sight holes on the bottom of the newly mounted tips. Insert the screws through the sight holes and into the metal clips, mounting securely.



- Mamotorworks
- @CorvettePassion
- MidAmericaMotorworks
- CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
 ©Mid America Motorworks, Inc. All rights reserved.