

Application: 1997–2004

INSTRUCTION SHEET

Part Number



Part Includes

1 - Component

Dual C5 Cupholder



Tools Needed

ioois needed

Preparation

STEP 1.

Remove original rubber cupholder liner.

STEP 2.

Position Dual C5 Cupholder as shown above.

STEP 3.

Drill a small pilot hole in the center of the bottom of the cup closest to the shifter, with a drill bit slightly smaller than the screw provided. Make sure hole is drilled through the console plastic.

STEP 4.

Install screw. Do not over-tighten.



Search: Pedals, Accelerator







@CorvettePassion

MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.

.....

