



Application: 1997-2004 Corvettes



Search: **C5 Interior LED Lighting Kits 1997-2004**
www.mamotorworks.com

C5 Rear Hatch/Trunk LED Light Bulb Kit



Tools Needed



Step 1. Pull the hatch/trunk light housing from the carpet to gain access to the back of the housing.



Step 2. Turn the bulb socket 1/4 turn counterclockwise to remove it. Pull the factory bulb out and insert the led. Replace the socket and lock it in place. If the led doesn't light remove the socket and turn it 180 degrees and re-insert it. It should now light. The lights will time out after about 15 minutes so keep that in mind if it doesn't light. Push the housing back into the carpet and repeat procedure on the other side.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.