



Application: 1997-2004 C5

Part Includes

1 - Component

Front Bumper Skid Plate



Tools Needed



Search: *Suspension and Chassis*
www.mamotorworks.com

STEP 1.

Prior to installation, make sure your transmission is in park and your parking brake is engaged.

STEP 2.

If your stock skid plate is distorted or bent, you must straighten it with a hammer for proper fit of the new unit.

STEP 3.

With the bolt holes facing upward, position the new skid plate over the stock plate so that the bends align.

STEP 4.

Install the bolts and nuts to each side and tighten to approximately 50 ft/lbs.

STEP 5.

Periodically check the alignment and tightness of bolts. Adjust as needed.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.