



Application: 1997-2004 Corvette

Part Includes

2 - Spoiler Reinforcement Plates

C5 Front Spoiler Reinforcement Kit



Tools Needed



Search: **Body Panels - Fiberglass**
www.mamotorworks.com

INSTALLATION

STEP 1.

Remove the 3 screws that secure the outer ends of the spoiler as shown above.

STEP 2.

Reinforcement plate is placed below the spoiler and the mounting flange on the underside of the car. Please note which side of the reinforcement piece faces down for the driver's side or passenger side of the car.

STEP 3.

Replace the 3 screws.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.