

Application: 2005–2007 Corvette

INSTRUCTION SHEET

Part Number

611-465

Part Includes

- 2 Stainless Fuel Rail Covers
- 1 Angle Chrome Cover w/Velcro
- 1 Adhesive Promoter Pack

C6 Corvette 2-pc Fuel Rail Covers












Your new covers come to you with a protective liner. Do not remove liner until installation is complete.

STEP 1. Your new fuel rail covers have been designed to snap over the existing factory covers. Simply remove the stock fuel rail covers and snap the new covers over top of them. Using a small rubber mallet tap the two small tabs over to lock in position and reinstall your covers.

STEP 2. Once you have successfully reinstalled your covers remove the protective liner.

STEP 3. You have been supplied with a small stainless fuel line cover to be placed over the fuel line via attachment putty on the C6 covers 05-07 ONLY. On the C5 covers the stainless fuel line cover just peels and sticks over the fuel line. Simply form and press in place.

STEP 4. You have been provided with a decorative chrome oil cap cover. Simply clean the top of the factory oil cap with household rubbing alcohol to remove and dirt and road grime then swipe



Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

If any questions occur during installation, please contact Mid America Motorworks at 1-800-500-1500.

Thank you and enjoy your new purchase!







Mamotorworks



@CorvettePassion





MidAmericaMotorworks



2900 North Third Street, Effingham, IL 62401 800.500.1500 · Worldwide: 217.540.4200 · FAX: 217.540.4800 www.mamotorworks.com · generalmail@mamotorworks.com OMid America Motorworks, Inc. All rights reserved.

.....